


Options - Pin-Relays:

Used for testing the relays on the relay boards.

1. Manual test

Click to test whether a relay switches (tests PCF8574, ULN2003A, relay coil. Does not test relay contacts)



2. Automatical test (hardware >= V9, software >= 10.2.7.0)

tests PCF8574, ULN2003A, relay coil, relay contacts. Please note: All cards must be present.

